



- INSTRUCTIONS FOR USE:
1. INSERT MT-RJ ASSEMBLY INTO TOOL UNTIL IT LATCHES IN PLACE
 2. SQUEEZE EXTRACTOR PINS TOGETHER
 3. WITH EXTRACTOR PINS SQUEEZED TOGETHER, GRASP BOOT ASSEMBLY AND REMOVE FROM HOUSING

EXTRACTOR PIN
X2

▲ DENOTES CRITICAL DIMENSION.

Material:		N/A	
REV.	DATE	DESCRIPTION	ECN
A	9/15/04	INITIAL RELEASE	00582
B	3/29/05	REVISED PART & DRAWING NUMBERS	00661

CUSTOMER DRAWING
DIMENSIONS FOR REFERENCE ONLY
THIRD ANGLE PROJECTION
METRIC/mm

USCONEC Hickory, NC
800-769-0944
www.usconec.com

TITLE
**ASSY, TOOL, HSG
REMOVAL, MTRJ**

SIZE	S&M Part No.:	DWG NO.	REV
B	7446	C7446	B
SCALE	Drafter	Date:	SHEET
N.T.S.	ioehoward	5/10/2004	1 OF 1